## "Tuff Farm" Tractor Pulls

Premium: 1st - \$100, 2nd - \$75, 3rd - \$50

Rules for "Tuff Farm":

- 1. 3000 RPMS will be checked at any time for safety.
- 2. 2 hooks only per tractor.
- 3. In order for a class to be a paying class, 3 or more tractors must be in class. Otherwise, it is an Exhibition only class.
- 4. No jumping to farm stock classes.
- 5. Replacement engines allowed. Must be direct bolt in application from tractor to manufacturer. Ex: JD 466 for 404, IH 466 for 414, 504 Case for 401.
- 1. PTO and hydraulics not needed.
- 2. Single turbo only (2 3/8 cross bolts).
- 3. 20" hitch height, 18" from axle.
- 4. No top link on hitch.
- 5. No cut tires.
- 6. Helmets and fire extinguishers for safety.
- 7. Must have fenders.
- 8. Entry Fee: \$20
  - Class 1. Tuff Farm 6000 lbs.
  - Class 2. Tuff Farm 8000 lbs.
  - Class 3. Tuff Farm 10,000 lbs.
  - Class 4. Tuff Farm 12,000 lbs